

**Application Note:
GSM2218AN001**

**Enfora® MT-GL
Quick Start Guide**
Revision 1.02

Enfora, L.P.
661 East 18th Street Plano, Texas 75074-5601
www.enfora.com

Objective:

The objective of this document is to provide the user with basic information on how to configure the modem and verify communication with Enfora's UDPAPI test server.

Equipment Needed:

In this example the requirements are:

- GSM2218 MT-GL
- Enfora Serial / Power cable Part number ADT2218 or
 - a. Connector WAGO 733-112 or equivalent
 - b. Wire minimum 20 AWG for 20 ft (max) for power.
 - c. DB9 female connector
- Power supply
- GSM quad band antenna
- GPS 3.3v Active antenna
- Computer with one available Serial port or USB-to-serial converter
- GSM/GPRS SIM with GPRS data enabled.
- An APN (Access Point Name).
- Username and Password, if GPRS is operating on a non-transparent network.

Note: If you don't know the name of the APN you need to use, please contact your cellular network carrier for that information. Once you have acquired this information, please complete **Application Note GSM0000AN019 – GSM Network Configuration Worksheet** and keep this worksheet for future reference.

References:

- GSM2218PB001MAN – Enfora® MT-GL Hardware User Manual
- GSM2000PB001MAN – Enfora® Mobile Tracker Software User Manual
- GSM0107PB001MAN - Enabler-IIG AT Command Set
- GSM0000AN019 – GSM Network Configuration Worksheet

Procedures:

1. Configuring the computer and verifying correct communications.

Note: The following examples use Windows 2000 and HyperTerminal. Any Terminal program should work, using the parameters in Step A.

- a. Default Serial Parameters


1. 115200 baud rate
2. 8 data bits
3. 1 stop bit
4. No Parity
5. Flow Control = None

- b. Determine which Com port to use


1. On older computers, there is usually a built in Com port. This is normally Com1
2. If you are using a USB-to-serial converter, you will need to determine which Com port it is installed on.

Note: If the USB-to-serial converter has not been installed, install the necessary drivers per the instruction supplied by your USB-to-Serial device. Then leave the device unplugged.


3. Open up the **System Properties** window. This is done through the **Control Panel > System** or right-click on **My Computer** and select Properties. Select the **Hardware Tab**. On Windows 2000 the screen looks like the following:



4. Select the **Device Manager** button. Expand the **Ports** section by selecting the + sign beside **Ports**. Your window should look like the following:



5. Plug in the USB-to-Serial converter. The window should change to show the USB-to-Serial converter installed.



6. Most devices will show the Com port next to the device name. Record this number. In this case, it is COM12.

Note: Make sure there is no “!” or “X” next to the USB device. If you see an “!” or an “X,” the device is not properly installed and will not work.

c. Start **HyperTerminal**

On **Windows 2000**, click on:

Start>Programs>Accessories>Communications>HyperTerminal


1. You should see the following screen.



3. Enter a name for the **Connection**. In this example, the **Name** is **Enfora Com1**.
4. Click **OK**.
5. The next window that will appear is the **Connect To** window.




6. Change the **Connect Using** setting to the Com port that was determined in **Step B**.
7. Click **OK**.
8. The next window is the **Port Settings** window.



9. Make sure the settings match the example.

10. Click **OK**.

11. Now the **Main Program Window** should appear.




d. Terminal Setup Testing.

1. Make sure the cursor is in the main window.
2. Start typing characters.
3. If all settings are correct, you should not see anything happening in the main window.
4. Jumper Pins 2 and 3 together on the Serial connector.
5. Start typing characters.
6. You should now see what you are typing appearing in the main window.
7. If this happens, the COM port is configured correctly.

2. MT-GL panel descriptions

a. Front Panel



b. Rear Panel



3. Preparing the Power and Serial Communications Cable

- a. Use a factory-built wiring harness with serial data option or build a wiring harness according to the following schematic.

Note: The **Ignition (pin 10)** is **Optional** and is used to sense an **Ignition On** event from the vehicle and will cause the modem to reset if power is removed and reapplied to this input.





Figure 3

4. Connecting the GSM/GPRS antenna

- a. Choose an antenna that is designed for the frequency band the in which the modem is currently going to operate. The antenna jack is a standard TNC Female.

Note: The antenna must have a nominal impedance of 50 Ohms. The VSWR must be less than 2.0:1. System antenna gain should be 0 – 2 dB for optimum performance.

- b. Attach the GSM/GPRS antenna to **Modem Ant** jack.



5. Inserting the SIM and applying power

Note: The SIM card is not provided with the MT-GL device. The SIM must be obtained from the GSM/GPRS service provider and must be provisioned by the operator for data and/or voice. Always take care to protect the SIM. Without the SIM installed, MT-GL modem is limited to emergency voice communication only.



Ensure the power to the MT-GL is disconnected before inserting the SIM card. Failure to do so might result in unusable MT-GL or a damaged SIM card.



Enfora is not liable for damages to the MT-GL when inserting a SIM card inside the device. (GSM2218 only).

- a. Insert the SIM per the following picture:



Insert the SIM into the SIM Slot with the notch going into the slot first, and facing toward the left side of the modem.

1. Slide the SIM Lock Door to the left to lock the SIM into the holder.

- b. Install the power cable as shown in the following picture:



1. Hook up the modem to a 12 Vdc power source and apply power.
2. The **Power LED** should be solid red and the **GSM Status LED** should start blinking green.
3. Once the modem attaches to the GSM network, the **GSM Status LED** should go solid green. If the **GSM Status LED** stays blinking, then there is a problem with the SIM or cellular reception.

6. Configure the Modem to talk to the Enfora Server


- a. Connect and verify Serial connectivity with the Enfora modem.

1. Connect the PC serial connector to the modem serial port.

Note: In the following instructions, **<CR>** means using the **Enter Key** on the keyboard.

2. With HyperTerminal open, hit the **Enter** key. The modem should respond with **OK**. If you do not see this response, double check your connections and perform the serial loop back test again.
3. Type **AT<CR>**. The modem should respond with **OK**. If you do not see the letters **AT**, send the following command to the modem: **ATE1<CR>**

4. Type **ATI<CR>** . The modem should respond with **Enfora, L.P.**
If you get any different response, you are not connected to the Enfora modem.



- b. Configure the Modem to communicate with the Enfora Test Server.

1. The following information will need to be obtained from the SIM provider. Please refer to GSM0000AN019 – Network Configuration Worksheet.
3. APN
4. Username and password (If necessary.)

Note: In the following examples, the SIM is for Cingular.

APN = isp.cingular
Username = ISP@CINGULARGPRS.COM
Password = CINGULAR1

4. Reset the modem to factory defaults:
 1. To restore the modem to factory defaults, send the following command:
AT&F<CR>
 2. To write current config to memory, send the following command:
AT&W<CR>

3. To reset the modem, send the following command:
`AT$RESET<CR>`
5. Configure the Modem to Access the GPRS network.
 1. To inform the modem of the proper APN, send the following command:
`AT+CGDCONT=1,"IP","apn"<CR>` (substitute the letters apn for the supplied apn.)
 2. To inform the modem of the proper username and password, (if necessary) send the following command:
`AT%CGPCO=1,"username,password",0<CR>` (substitute the correct username and password)
 3. To configure the modem to enable auto GPRS registration, send the following command:

`AT$AREG=2<CR>`
 4. Store the current configuration to memory, send the following command:
`AT&W<CR>`
 5. Reset the modem by removing power or sending the **`AT$RESET<CR>`** command.
 6. Verify GSM status by sending the following command:


`AT+CREG?<CR>`
If everything is working, you should receive one of two responses:

`+CREG: 0,1` (GSM registered to home network)
`OR`
`+CREG: 0,5` (GSM registered roaming.)
 7. Verify GPRS status by sending the following command:

`AT%CGREG?<CR>`

If everything is working, you should receive one of two responses:

`%CGREG: 0,1` (GPRS registered to home network)
`Or`
`%CGREG: 0,5` (GPRS registered roaming.)




```
AT&F
OK
AT&W
OK
AT-Command Interpreter ready
AT+CGDCONT=1,"IP","isp.cingular"
OK
AT%CGPCO=1,"ISP@CINGULARGPRS.COM,CINGULAR1"
OK
AT$AREG=2
OK
AT&W
OK
AT-Command Interpreter ready
AT+CREG?
+CREG: 0,1

OK
AT%CGREG?
%CGREG: 0, 1

OK
```

8. Verify GPRS activation by sending the following command: AT\$NETIP?<CR>

If the response is non-zero, then everything is working.
Skip to Step 10.



```
AT%CGPCO=1,"ISP@CINGULARGPRS.COM,CINGULAR1"
OK
AT$AREG=2
OK
AT&W
OK
AT-Command Interpreter ready
AT+CREG?
+CREG: 0,1

OK
AT%CGREG?
%CGREG: 0, 1

OK
at$netip?
$NETIP: "166.170.006.159", "066.102.163.231", "066.102.163.232"

OK
at$cger
$CGEER: no PDP reject cause

OK
-
```


9. If AT\$NETIP returns all zeros, send the following command: AT\$CGEER<CR>

- There are three common responses:
 - \$CGEER: no PDP reject cause (Everything should be working OK)
 - \$CGEER: requested service option not subscribed (APN is incorrect or SIM has not been enabled for data mode.)
 - \$CGEER: user authentication failed (username and/or password is incorrect.)

10. Configure the modem to access the Enfora Server.

Note: To configure the modem for server interoperability, several things have to be addressed:

- Most GPRS configurations are Mobile Originate only. The mobile modem must initiate a conversation with a remote server before the remote server can talk to the modem.
- IP addresses are dynamically assigned and can change.
- Some IP addresses are NAT and are non-routable IP addresses.

These issues are addressed with the following configuration commands.

The examples will use the following information:

- Modem ID/name = "MT_Test"
- Remote Server IP address = 67.103.214.214
- Remote Server IP port = 1721

11. Give the modem a unique name.

- Send the following command: AT\$MDMID="MT_Test"
This command, combined with the wakeup message, will allow the server to associate a Public IP address with a specific modem and create a window of opportunity where the server can send commands to the modem

12. Configure the modem to talk with a specific server.


- Send the following command:
AT\$FRIEND=1,1,"67.103.214.214"

13. Set the port number

- Send the following command: AT\$UDPAPI=,1721

14. Enable periodic messages (wakeup) to be sent to the server every 60 seconds

- Send the following command: AT\$WAKEUP=1,1




```
Enfora Com1 - HyperTerminal
File Edit View Call Transfer Help
[Icons]
AT$MDMID="MT_Test"
OK
AT$FRIEND=1,1,"67.103.214.214"
OK
AT$UDPAPI=,1721
OK
AT$WAKEUP=1,1
OK
-
Connected 0:07:33  Auto detect  115200 8-N-1  SCROLL  CAPS  NUM  Capture  Print echo
```


7. Verifying Server connectivity.

Note: For the following tests, Java Runtime must be installed on the computer. (To install Java Runtime, please visit the Java website here: <http://www.java.com/en/download/manual.jsp>)


- Start Internet Explorer and enter the following URL:
<http://67.103.214.214/udpapp/>
- Enter the name used in the MDMID command in the box. Select **Connect**.



- c. Select the tab with the modem name. Within approximately 60 seconds the wakeup messages should be seen in the window.



- d. Enter the following command in the command/ data block: **ATI**
- e. Select **Write**.
- f. Verify that you see the following the modem response with Enfora, L.P.
If so, you have successfully configured the modem to talk with the server.




8. GPS Operation and verification

The GPS receiver inside the MT-GL provides power to the pre-amplifier in the GPS antenna (Active-style) by applying a power of 3.3 Volts to the center conductor of the RF input to the GPS receiver. If a passive-style GPS antenna must be used, please verify that it has a DC block installed in order to prevent shorting to ground. The GPS antenna connector on the MT-GL model is an SMA female connector. The GPS antenna must be placed in an area where it can have direct view of the sky.



User must disconnect power before connecting the GPS antenna

- a. Install the GPS antenna to the GPS ANT jack on the MT-GL modem.



GPS Antenna

b. After a couple of minutes, the GPS status LED should switch to solid red. When this happens, the GPS receiver has enough information to track the current position.


c. Verify GPS operation.

1. From the terminal window, send the following command:
AT\$GPSRD=10<CR>
2. The modem should respond with a standard GPRMC message that looks similar to the following:

```
$GPRMC,221223.00,A,3301.5080,N,09642.3857,W,000.0,000.0
,230805,05.9,E,A*19
```

Note: The entry shown in bold is the current GPS status. There are three possible values here:

- A = OK
 - V = Warning
 - 9 = Enfora Specific response that GPS solution is not valid and the last known GPS location is being substituted.
3. Here is an example of a GPRMC message without a GPS lock:
\$GPRMC,221553.30,V,,,,,,,,,N*7C
 4. The same command can be used in the server app.



Revision History

Date	Rev	Author	Description
08/08/05	1.0	Calvin French	Initial release.
07/05/06	1.01		Added step 13 on page 15
07/31/06	1.02	Diane O'Neil	Changed IP address of test server